

Ted the Telephone Guy

Ted Woods, LLC • P. O. Box 231 • Centerville, MA 02632 • 508-419-7225

How to Change the Date and Time on Your Toshiba Strata DK Series Telephone system

From the attendant's extension:

1. With the phone on-hook, press **Intercom**
2. Dial **#652**
3. Dial the appropriate **6** digits to enter the time in **HHMMSS** format* using 24-hour (military time) notation.
4. Press **Redial** (or dial #)
5. Press **SPK** to hang up

*Enter the time using **HHMMSS** (hours, minutes and seconds) format and 24-hour time notation. Time is from 000000 (midnight) to 235959 (11:59 p.m.). Since a time entry must have 6 digits, use leading zeros when necessary. For example, dial 090000 for 9:00 a.m. For 9:00 p.m. dial 210000. For 2:15 a.m. dial 021500. For 2:15 p.m. dial 141500. For 4:45 p.m. dial 164500.